



LENZE AC TECH VFD



VFD KEYPADS IN E-BOX

SUPPLEMENTAL MANUAL

FACTORY-INSTALLED LENZE AC TECH VARIABLE FREQUENCY DRIVES (VFD) IN RENEWAIRE (ERV) VENTILATORS

TABLE OF CONTENTS

Product info	2
Installation	3-9
Operation	10-16

LENZE AC TECH VARIABLE FREQUENCY DRIVES

PRODUCT INFO

ABOUT LENZE AC TECH VFDS

This manual supplements RenewAire's standard Installation & Operation Manuals, which do not include information on units equipped with ACTech/Lenze VFDs. RenewAire uses ACTech/Lenze VFDs for some models, typically those using a 575VAC power supply.

FOR COMPLETE ERV INSTALLATION YOU WILL ALSO NEED:

- **Standard Installation and Operation Manual for the ERV** – physical installation and duct connection, maintenance procedures, etc.
- **Supplemental Wiring Schematic Manual** – complete unit wiring diagrams.
- **SMVector-Frequency Inverter Operating Instructions** – Lenze AC Tech's users/installers manual. More information is available online in the Technical Library at www.lenze-actech.com.

PLANNING YOUR INSTALLATION

WARNING

RISK OF FIRE, ELECTRIC SHOCK, OR INJURY. OBSERVE ALL CODES AND THE FOLLOWING:

1. Before servicing or cleaning the unit, switch power off at disconnect switch or service panel and lock-out/tag-out to prevent power from being switched on accidentally. More than one disconnect switch may be required to de-energize the equipment for servicing.
2. This installation manual shows the suggested installation method. Additional measures may be required by local codes and standards.
3. Installation work and electrical wiring must be done by qualified professional(s) in accordance with all applicable codes, standards and licensing requirements.
4. Any structural alterations necessary for installation must comply with all applicable building, health, and safety code requirements.
5. This unit must be grounded.
6. Use the unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer.
7. When cutting or drilling into unit, wall or ceiling, do not damage electrical wiring and other hidden utilities.
8. Do not re-wire the VFD(s) to control more than one motor per VFD.
9. Do not operate the motors in this unit above the motor's rated full load amps (FLA) as indicated on the unit's nameplate.

NOTE: VFD(s) in this unit can be operated in many ways. This Manual provides only an outline of common methods.

CAUTION

DO NOT OPERATE VFD IN CONDITIONS OUTSIDE OF TEMPERATURE LIMITS. The manufacturer's ambient temperature limits for the VFDs are 14 to 131 °F. It is not recommended that the VFDs be used under conditions above or below these temperature limits. Operate outdoor ERV units continuously if outdoor design conditions are not within the VFD operating temperature range or make other provisions to bring the VFD operating condition into the acceptable ambient temperature range. RenewAire commercial ERVs are VFD ready, in extreme climates consider field installing VFDs in a climate controlled indoor electrical cabinet.

“ON” AND “SPEED” SIGNALS

VFD operation in this unit is dependent on two signals: an ON signal and a SPEED (or REFERENCE) signal. The sources and types of these signals can vary. If the ERV is equipped with dampers the ON signal to the VFD comes from the end switch on the damper. If the ERV is not equipped with dampers, the ON signal comes from an external control connected directly to the VFD. When an ON signal is received by the VFD, it starts the motor. The VFD then operates the blower at the speed established by the SPEED signal. The SPEED signal is often provided by an external control, but in some applications “pre-set” speeds are set inside the VFD and are selected by external switches or relays.

PRINCIPLES OF EXTERNAL CONTROL

This ERV can be operated by various external control devices including remote switch or relay, digital time clock with relay, occupancy sensor with relay, and carbon dioxide sensor with relay and analog output. These devices are commonly known as 2-wire, 3-wire, and 4-wire devices. A Building Management System (BMS) can control this ERV through relay contacts and with 0-10vdc or 4-20mA analog inputs.

The external control devices can be connected to this ERV to operate each blower independently or for one blower to act as leader and the other blower to act as follower. In leader-follower mode, a single external switch or relay calls for operation and the leader VFD sets SPEED to internal presets, or in response to an analog input signal. The follower VFD then operates at either exactly the same speed, at an offset above or below the leader’s speed, or at a scaled speed.

The VFD’s are pre-programmed at the factory so only a few parameters need change for a specific installation.

CONNECTING EXTERNAL CONTROLS

If this ERV is equipped with damper(s), the ON signal is connected to the terminal strip in the electrical enclosure (“E-box”). If this ERV is not equipped with damper(s), and has 2 VFDs, the ON signal is connected directly to the VFDs. The SPEED signals are always connected directly to the VFD(s).

WIRE ROUTING

Route input power cables, motor cables and control cables separately to decrease electromagnetic interference caused by the rapid changes in the drive output voltage. Where control cables must cross power cables make sure that they are arranged at an angle as near to 90 degrees as possible.

Power cables and control cables can be brought into the bottom of the electrical box attached to the ERV unit or through the bottom of the unit itself. There are plugged holes to run control wires and power wires between the electrical box and the unit interior, marked on the interior of the ERV unit and another plugged hole in the unit compartment divider to run wires to VFDs in the other airstream compartment if needed.

In some configurations the VFD and/or VFD protective guard may need to be removed to access the control wire hole plug to run wires. A label is located in the ERV on the left interior wall indicating the power and control wire hole plug locations. Bring wires out from the top or bottom of the VFD mounting bracket and not through the mounting bracket window when routing wires if the VFD is mounted over the hole plug.

After the wires are run, apply caulk around the wires at wire bushings used between the electrical box and ERV unit and between compartments in the unit to prevent air leakage between these compartments.

PLANNING YOUR INSTALLATION

LENZE AC TECH VARIABLE FREQUENCY DRIVES

INSTALLATION

PLANNING YOUR INSTALLATION


PURPOSE OF PROVIDED KEYPAD

Each VFD has a keypad which is accessible at the E-box while the unit is operating.

You can check the status of the VFD at the keypad, and make changes to the VFD parameters at the keypad. You can manually control the VFD from the keypad during start-up and commissioning.

VFD is factory programmed to cover most needs but some parameters will need to be set to interact with the external control system.

Access the keypad(s) through the removable cover to the E-box.



TECHNICAL SUPPORT

For questions about applications not covered in this manual, and for questions specific to the Lenze AC Tech Drives, contact Lenze AC Tech Technical Support at **800-217-9100** or **(508) 278-9100**.

A listing of Lenze AC Tech support and service contacts can be found on the Internet at www.lenzeactech.com/drives and selecting Support and Library.

Lenze AC Tech manuals are available as PDFs at www.lenze-actech.com; select Technical Library. Lenze AC Tech offers training courses on their VFDs; navigate to www.lenze-actech.com/drives and select Training Schools.

For questions about applications covered in this manual, and for questions about how the VFDs are installed in your RenewAire ERV unit, contact RenewAire Customer Support at **800-627-4499**.

INSTALLATION

“ON” SIGNAL CONNECTIONS

Depending on features installed, connect ON-SIGNAL connections either to the VFDs themselves, or to the low-voltage terminal strip in the ERV E-box. See schematics below.

Install a jumper between terminals 2 and 3 to use the ERV's on-board 24VAC power. Do this when the external control(s) have isolated contacts that don't provide any voltage, as in the top two examples. Make no connections between terminals 1 & 2 and terminals 3-5 if the external control has a voltage output to provide the ON signal. This voltage must be 24VAC.


WIRING OPTIONS

WARNING

Capacitors in VFDs Retain Charge

Allow 3 minutes after shutting off power to the VFDs to allow the capacitors in the VFD to fully discharge. Do not connect or disconnect wires at the VFD without waiting 3 minutes.

WIRING SCHEMATICS



LENZE AC TECH VARIABLE FREQUENCY DRIVES

INSTALLATION



WIRING SCHEMATICS

F2 FACTORY CONTROL WIRING: ON SIGNALS CONNECTED TO EACH VFD.

See Fig. 1 for Relay or Damper Actuator Connection alternatives.

NOTE:
ERV may optionally have only one VFD.

DO NOT CONNECT POWER TO TERMINALS 1 & 4



F3 ALTERNATIVE CONTROL WIRING: ON SIGNAL CONNECTED DIRECTLY TO ONE VFD, PASSED TO SECOND VFD FROM TERMINALS 16 & 17.


Speed Input Wiring Not Shown

DO NOT CONNECT POWER TO TERMINALS 1 & 4

Speed Input Wiring Not Shown

Close contact to turn FA Blower ON.

Install these wires - FA VFD will turn EA Blower ON.



PARAMETER SETTINGS - FA VFD

Parameter	Setting	Parameter Description
P140	1 = RUN	Closes contact between 16 & 17 when VFD is called to RUN.


ANALOG INPUTS TO PROVIDE THE SPEED SIGNAL

Analog inputs are connected as shown below. It may be necessary to scale the response of the VFD to the analog SPEED signal.


NOTE: All wiring for analog signals connected to the VFDs should be double- or single-shielded twisted-pair cable. Ground the shield at one end of the cable only. The grounding clamp on the VFD may be used.

WIRING SCHEMATICS

F4 EXAMPLES OF ANALOG INPUT CONNECTIONS.



Connections for 0-10vdc Controller.



Connections for 4-20mA Controller.

PARAMETER SETTINGS - 0-10vdc ANALOG INPUT		
Parameter	Setting	Parameter Description
P201	1	Enables use of 0-10vdc input.

PARAMETER SETTINGS - FA VFD		
Parameter	Setting	Parameter Description
P201	0	Enables use of 4-20mA input

WIRING TWO VFDs FOR LEADER-FOLLOWER OPERATION


One VFD can provide the SPEED signal to a second VFD, as shown below.

NOTE: If the FA VFD is controlled by an analog input signal, it is likely that the FA VFD's response to the analog input will need to be scaled. See "SMVector – Frequency Inverter Operating Instructions" – Lenze/AC Tech's user's/installer's manual.

Parameter P152 TB-30 Scaling Frequency can be used to scale the Analog Output of the Leader VFD in order to offset or correct the speed of the Follower VFD.

If both VFDs are to run at the same speed, no scaling parameters need be applied to the EA VFD since it is controlled as a "Follower".

F5 LEADER-FOLLOWER CONNECTION.



PARAMETER SETTINGS - LEADER VFD		
Parameter	Setting	Parameter Description
P150	1	Sets analog speed output as 0-10vdc

PARAMETER SETTINGS - FOLLOWER VFD		
Parameter	Setting	Parameter Description
P201	1	Enables use of 0-10vdc input

LENZE AC TECH VARIABLE FREQUENCY DRIVES

INSTALLATION

WIRING SCHEMATICS USING VFD PRESETS FOR THE SPEED SIGNALS

The VFD can be programmed with 3 pre-set speeds. Switches can then be used to direct the VFD to operate at one of those speeds. See Lenze AC Tech manuals for additional options. Leader-follower wiring can also be used to make a second VFD operate at the same speed as the first VFD.

NOTE: Pre-set speeds override any Frequency (Speed) inputs.

Install Leader-Follower connection wiring if desired to operate 2nd VFD at the same speeds.

F6 USE OF 3 SWITCHES TO COMMAND THE VFD TO OPERATE AT ANY OF 3 PRE-SET SPEEDS (SP4T SWITCH CAN ALSO BE USED).

PARAMETER SETTINGS		
Parameter	Setting	Parameter Description
P121	3	Enables operation at Preset Speed 1
P122	3	Enables operation at Preset Speed 2
P123	3	Enables operation at Preset Speed 3

Do not disconnect factory wiring from Terminals 1 & 4 to Relay Contact, Actuator End Switch, or external ON Contact.

The desired preset speeds are set at Parameters P131-P133. AC Tech allows up to 7 presets. Values as shipped from factory are shown below:

PARAMETERS	VALUE AS SHIPPED FROM RENEWAIRE	PARAMETER DESCRIPTION
P131	30 Hz	Preset Speed #1
P132	45 Hz	Preset Speed #2
P133	60 Hz	Preset Speed #3

OPERATION

INSTALLATION INSTRUCTION

USE WITH A BUILDING MANAGEMENT SYSTEM

The Lenze AC Tech SMVector drive can be connected to an external control system. The drive supports Modbus RTU, CANopen®, DeviceNet®, Ethernet, Profibus® and Lecom-B® Protocols. An I/O Module can also be installed. The SMVector drive can be upgraded in the field with communication modules sold by others. They snap into the drive terminal cover and are ready to connect to the network. See the Lenze AC Tech SMVector Drives User's Manual for details on connecting to an external control system.

INITIAL STARTUP

TO START ERV

1. Turn off power to the ERV at its Disconnect Switch. Make sure the ERV is wired to provide an ON signal. (See Control Wiring Schematics later in this Manual.) You may need to install a temporary jumper at the ERV or VFD low-voltage terminal strip.
4. To transfer control of the VFD to a control system: Press the STOP button on the keypad. Motor should stop running.

VFDs are set at the factory to respond to the keypad. If an external controller providing an analog input is connected to the VFD, you may want to temporarily disconnect it.

Change the VFD parameters as required for the specific controls system (see "Control Connections" and "VFD parameters", below, for examples; see also the Lenze AC Tech Manuals.)

Close ERV doors and main cover for the E-box; leave keypads accessible.

2. Turn on power to the ERV at its Disconnect Switch. Wait for keypad display to appear.
3. For each VFD:
Press the RUN button on the keypad. Motor should start running at about 425 RPM.

Use the UP/DOWN buttons to set motor speed as desired. Confirm the motor amps are no greater than the motor FLA as listed on the unit nameplate using parameter P508 (see section on how to view VFD parameters).

MOTOR PROTECTION BY THE VFD(S)

Each VFD in this unit protects one motor against overload. It is critical that the VFD Motor Overload be properly set using the Full Load Amps (FLA) of the motor. The following Parameter must be set correctly and individually for each VFD to match the characteristics of the motor attached to it:

$P108 \text{ MOTOR OVERLOAD} = \text{motor FLA/VFD output rating} \times 100\% \text{ P165 BASE VOLTAGE}$

These parameters are set at RenewAire to match the motor controlled by the VFD. In most cases they should not be changed.

VFD PARAMETER OVERVIEW

“VFD Parameters” are instructions that the Variable Frequency Drives follow. They can be adjusted by using the keypads on the VFDs. In some control configurations, they will need to be changed from the settings as shipped in the unit to interface with your control system.

TO VIEW ALL VFD PARAMETERS

VFD must be powered up – something will be showing on the LED display.

1. Push MODE button – PASS will flash on screen followed by “0000”.
2. Push MODE button again to display P498.
3. Use UP or DOWN arrows to scroll through the Parameters.
4. Press MODE button to display the Parameter value.
5. Press MODE to exit – STOP will display.
6. To view other parameters start process over.

TO CHANGE VFD PARAMETERS

VFD must be powered up – something will be showing on the LED display.

IF PASS CODE is enabled (i.e. P194 is set to something other than “0”):

1. Push MODE button – PASS will flash on screen followed by “0000”.
2. Press and hold UP Button to scroll to password 225.
3. Press MODE; P100 will be displayed.
4. Proceed to step 6, below.

If PASS CODE is NOT enabled (i.e. P194 is set to “0”):

5. Press MODE button; the last-viewed Parameter will be displayed.
6. Use UP or DOWN Button to scroll to Parameter of interest.
7. Press MODE Button; Parameter value will be displayed.
8. Use Up/Down Arrow button to change parameter value.
9. Press MODE button to save changed parameter value.
10. Press MODE button to exit; STOP will be displayed (in some cases the display will be different).

SETTINGS

LENZE AC TECH VARIABLE FREQUENCY DRIVES

OPERATION

SETTINGS SUMMARY TABLE OF COMMONLY USED PARAMETERS

Name/Selection	Default	Settings as Shipped BY RenewAire	FUNCTION	
P100	Start Control Source	0	2	2=Sets the source of the START command is the keypad in the unit E-box. Change to 1=Terminal Strip to enable on/off controls connected to terminal strip.
P101	Standard Reference Source	0	0	1=Enables 0-10vdc input to VFD. 2=Enables 4-20mA input to VFD.
P102	Minimum Frequency (Hz)	0	15	Determines the minimum operating speed for the blower.
P103	Maximum Frequency (Hz)	60	60 (90 Hz LE units)*	Determines the maximum operating speed for the blower.
P104	Acceleration Time 1 (sec)	20	20	Blower Speed Acceleration Time
P105	Deceleration Time 1 (sec)	20	20	Blower Speed Deceleration Time
P108	Motor Overload	100	Set per motor	CRITICAL SAFETY PARAMETER P108 = Motor FLA / VFD Output Amp Rating X 100
P121	TB-13A	0	0	Determines what action the VFD takes when a TB-13x is shorted to terminal 4. Setting "0" means VFD ignores these terminals. Change to "3" to enable use of Preset Speeds.
P122	TB-13B	0	0	
P123	TB-13C	0	0	
P131	Preset Speed #1 (Hz)	0	30	Determines VFD speed when the Preset is selected. Parameter value equals operating speed in hertz.
P132	Preset Speed #2 (Hz)	0	45	
P133	Preset Speed #3 (Hz)	0	60	
P140	Relay Output, TB-16, TB-17	0	1	"1" enables the output. "0" disables the output.
P150	TB-30 Output	0	1	Determines what the 0-10VDC or 4-20mA signal available at Terminal 30 indicates VFD Frequency, Load, Torque or Power. "0" = disables all output from Terminal 30. "1" = enables 0-10vdc Frequency Output "2" =enables 4-20mA Frequency Output.
P152	TB-30 Scaling: Frequency	60	60 (Hz)	Can be used to scale the analog signal at TB-30.
P160	Speed at Minimum Signal	0	0 (Hz)	When analog input is used to control VFD speed, sets VFD speed in hertz when analog signal is 0%.
P161	Speed at Maximum Signal	60	60 (Hz)	When analog input is used to control VFD speed, sets VFD speed in hertz when analog signal is 100%.
P165	Base Voltage	--	575V	Must equal motor nameplate voltage
P194	PASSWORD	225	0	"0" = password disabled Must enter"225" to access parameters.
P400	Network Protocol	0	1	"1"=Remote Keypad

* Maximum Frequency set higher in LE units to generally operate motors near 60 Hz or faster resulting in higher motor output HP.

SCALING AND RESPONSE TO ANALOG INPUTS

The most likely reason to control the VFD from an analog signal is automatically change the amount of outside air ventilation to meet the actual needs for each time period.

If one or both of the VFDs will be controlled by an analog input from an external Control Device (e.g. a CO2 controller or a Building Management System), you may need to “scale” the rate of response of the VFD(s) to the rate of change of the analog signal. Usually only one of the two VFDs requires scaling.

We need to introduce two concepts relating to the amount of outside air ventilation needed in the building:

- The “ACTION LEVEL” (AL) is the level of measurement of indoor air quality or occupancy at which the ERV Unit should start to deliver more than the “Design Minimum Supply Airflow”;
- The “MAXIMUM RESPONSE LEVEL” (MRL) is the level of measurement of indoor air quality or occupancy at which the ERV Unit should be operating at the “Design Maximum Supply Airflow”.

ADDITIONAL JOB INFORMATION NEEDED:

1. INPUT TYPE (IT) of analog signal: vdc or mA
2. MINIMUM SIGNAL VALUE (MinSV) of the analog signal: e.g. 0vdc or 4mA.
3. MAXIMUM SIGNAL VALUE (MaxSV) of the analog signal: e.g. 10vdc, 20mA
4. MEASUREMENT RANGE (MR): the range of the values that can be measured by the Control Device (e.g. a controller set to measure CO2 from 0ppm to 1100ppm).
5. ACTION LEVEL SIGNAL (ALS): the value of the analog signal corresponding to the “Action Level”.
6. MAXIMUM RESPONSE LEVEL SIGNAL (MRLS): the value of the analog signal corresponding to the “Maximum Response Level”.
7. MAXIMUM HERTZ (MaxH): VFD frequency setting at maximum design airflow. This was determined during the initial balancing process.
8. MINIMUM HERTZ (MinH): setting corresponding to minimum design airflow, again determined during the initial balancing process.
9. Whether ventilation should stop whenever air quality is below the “Action Level”, or should continue at minimum design airflow.

APPLICATION EXAMPLE: CO2 CONTROLLER

Consider the following building provided with outside air ventilation by an ERV Unit:

- The engineer requires a minimum outside air ventilation rate of 700 CFM at all times in order to control the level of indoor air pollutants generated by the furnishings.
- To address the higher level of ventilation required when the building is occupied, the engineer specifies that a CO2 controller shall be used to increase ventilation if CO2 levels rise above 600ppm.
- The engineer specifies a maximum outside air ventilation rate of 1500 CFM and expects this to restrain CO2 levels to 1000ppm.

In short, the ventilation requirements call for the ERV Unit to be running at no less than 700CFM at all times. When CO2 levels increase above 600ppm, the airflow volume should increase, reaching a maximum of 1500CFM at a CO2 level of 1000ppm.

Turning to the equipment itself:

- The CO2 controller is set up to deliver a linear 0-10vdc signal over a measurement range of 0 to 1100ppm.
THEREFORE: the “INPUT TYPE” (IT) = vdc.
The MINIMUM SIGNAL VALUE (MinSV)= 0vdc.
The MAXIMUM SIGNAL VALUE (MaxSV)= 10vdc.
The MEASUREMENT RANGE (MR) = 0 – 1100ppm.
- During Balancing we recorded VFD frequencies of 50hz at 1500 CFM, and 20hz at 700CFM.
THEREFORE: “MAXIMUM HERTZ (MaxH) = 50.
“MINIMUM HERTZ” (MinH) = 20.
- From the engineer’s requirements:
the “ACTION LEVEL” = 600ppm;
the “MAXIMUM RESPONSE LEVEL” = 1000ppm.

SETTINGS

OPERATION

SETTINGS APPLICATION EXAMPLE: CO2 CONTROLLER

We must calculate the ACTION LEVEL SIGNAL (ALS), the value of the analog signal coming from the controller when CO2 = 600ppm:

$$ALS = MinSV + \left[\frac{ACTION_LEVEL}{MR} \times MaxSV \right]$$

Or, in this example:

$$ALS(vdc) = 0(vdc) + \left[\frac{600(ppm)}{1100(ppm)} \times 10(vdc) \right] = 5.5(vdc)$$

We must calculate the MAXIMUM RESPONSE LEVEL SIGNAL (MRLS): the value of the analog signal coming from the controller when CO2 = 1000ppm:

$$MRLS = MinSV + \left[\frac{MRL}{MR} \times MaxSV \right]$$

Or, in this example:

$$MRLS(vdc) = 0(vdc) + \left[\frac{1000(ppm)}{1100(ppm)} \times 10(vdc) \right] = 9.1(vdc)$$

Now we can set the VFD parameters that will scale the response of the VFD to the inputs from the CO2 controller (see table on page 15):

Set Parameter 101 STANDARD REFERENCE SOURCE to "1", telling the VFD to expect a 0-10vdc signal.

Set Parameter 102 MINIMUM HERTZ: to "20". The VFD will never operate the motors below this speed.

Set Parameter 103 MAXIMUM HERTZ to "50". The VFD will never operate the motors above this speed.

Set Parameter 160 SPEED AT MINIMUM SIGNAL to the following calculated value:

$$P160 = P102 - \left[\frac{(P103 - P102)}{(MRLS - ALS)} \times (ALS - MinSV) \right]$$

Or, in this example:

$$P160(hz) = 20(hz) - \left[\frac{(50 - 20)(hz)}{(9.1 - 5.5)(vdc)} \times (5.5(vdc) - 0(vdc)) \right] = -25.8(hz)$$

Do not be concerned if this P160 is a negative number or is lower than the desired minimum – Parameter 102 will maintain VFD speed above this level.

Set Parameter 161 SPEED AT MAXIMUM SIGNAL to the following calculated value:

$$P161 = P103 + \left[\frac{(P103 - P102)}{(MRLS - ALS)} \times (MaxSV - MRLS) \right]$$

Or, in this example:

$$P161 (hz) = 50(hz) + \frac{(50 - 20)(hz)}{(9.1 - 5.5)(vdc)} \times (10 - 9.1)(vdc) = 57.5 (hz)$$

Do not be concerned that this setting is higher than the desired maximum – Parameter 103 will cap VFD speed below this level.

Ventilation can continue at analog signals below the CO2 concentration ACTION LEVEL.

In this application example the ERV Unit is intended to run continuously. If the measured CO2 concentration is below the ACTION LEVEL, the unit should run at the MINIMUM DESIGN AIRFLOW established by P102. To ensure that this happens, P215 MAX ALARM LEVEL should be set equal to P102 MINIMUM HERTZ.

However, if it were desired to shut down the ERV Unit at all CO2 levels below the ACTION LEVEL, set P215 MAX ALARM LEVEL equal to the ACTION LEVEL SIGNAL.


PARAMETERS USED IN SCALING

Parameters		Values
P101	Standard Reference Source	0 = Keypad 1 = 0-10vdc 2 = 4-20mA 3-5 = Preset #1 - #3 6 = Network
P102	Minimum Frequency	Input the value in hertz
P103	Maximum Frequency	Input the value in hertz
P160	Speed at Minimum Signal	Input the value in hertz. This value may be negative but this does not call for reverse rotation.
P161	Speed at Maximum Signal	Input the value in hertz. This value may be higher than the desired maximum blower speed.
P215	Max Alarm Level	Input the value in vdc or mA, whichever you are using.

LENZE AC TECH VARIABLE FREQUENCY DRIVES

OPERATION

SETTINGS EXAMPLES OF VFD SCALING



USA
(800) 627-4499
FAX: (608) 221-2824
201 RAEMISCH ROAD
WAUNAKEE, WISCONSIN 53589 USA
WWW.RENEWAIRE.COM

CANADA
(905) 475-8989
FAX: (905) 475-5231
WWW.MITSUBISHIELECTRIC.CA

**MEXICO,
CENTRAL & SOUTH AMERICA**
52 (222) 2 233 911
FAX: 52 (222) 2 233 914
WWW.SOLER-PALAU.MX