

ABBREVIATIONS

EA: Exhaust Air to outside
 OA: Outside Air intake
 RA: Room Air to be exhausted
 FA: Fresh Air to inside
 RTV: Rooftop Vertical RA & FA
 RTR: Rooftop Vertical RA Only

INSTALLATION ORIENTATION


Unit must be installed in orientation shown.

NOTE


1. UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE ROUNDED TO THE NEAREST EIGHTH OF AN INCH.

2. SPECIFICATIONS MAY BE SUBJECT TO CHANGE WITHOUT NOTICE.


CURB CROSS-SECTION A-A (TYP.)




SECTION A-A



LEFT VIEW



FRONT VIEW



RIGHT VIEW

Model: LE10X RTV/RTR
 Drawing Type: Unit Dimension
 Version: MAY18

